


PART NUMBER: **D194RKRCC, D194RKRS4**
 PRODUCT: **RKR RAILS / DETACHABLE STEPS**
 APPLICATION: **2019-C RAM 1500 CREW CAB**

PARTS INCLUDED	QTY
Step Rail	2
Detachable steps (pair) With Prt# D194RKRCCS4 <u>ONLY</u>	2


DO NOT USE IMPACT TOOLS

HARDWARE DESCRIPTION	QTY.
Kit # HWKT-00031X	
M8-1.25 HX FLANGED NUT	18



Shown with optional detachable step prt# JPTS32
 Or purchase of prt# D194RKRCCS4

Step 1: Locate the driver side step rail.



Step 2: Starting with the driver side, remove any steps and old hardware from the vehicle.



Step 3: On the inside rocker panel there will be three-attachment point consisting of three 8mm studs coming out from the panel. These studs may be covered in paint and will need to be cleaned before the installation.



Step 4: Carefully install the Predator Pro step to the three factory attachment points using the provided M8 flanged hex nuts. Leave finger tight for now.



Step 5: Next, adjust the RAILS up snug and parallel with the cab of the vehicle and tighten all rocker panel brackets to 30 ft/Lbs. *DO NOT USE POWER TOOLS.*



Detachable step Install Instructions.

(If purchased prt# **D194RKRC** or Detachable step prt# **JPTS32**)

Step 1. Attach the step to the step mounts using the supplied 1/2" bolts and lock nuts.

NOTE: *The step will mount to the left side of the mounts.*

Step 2. Torque hardware to 40 ft/lbs .

