

I-SHEET NUMBER: INST-00103 PART NUMBER: F194RKRCC , F194RKRCCS4 PRODUCT: RKR RAILS APPLICATION: 2019 + FORD RANGER CREW CAB







| PARTS INCLUDED          | QTY |
|-------------------------|-----|
| PRT# F194RKRCC          |     |
| DRIVER SIDE RAIL        | 1   |
| PASSENGER SIDE RAIL     | 1   |
| PRT# F194RKRCCS4        |     |
| DRIVER SIDE RAIL        | 1   |
| PASSENGER SIDE RAIL     | 1   |
| DETACHABLE STEPS (PAIR) | 2   |

| HAF    | RDWARE DESCRIPTION   | QTY. |
|--------|----------------------|------|
| HWKT-  | 04239X               |      |
| FHLB   | M10x25mm HEX FLANGED | 12   |
| 04240X | BOLT                 | 12   |

## DO NOT USE IMPACT TOOLS





**STEP 2:** Remove any factory running boards or hardware and discard. **STEP 3:** Clean/tap the three factory threaded mounting locations.



**STEP 4:** Carefully place step into place and loosely fasten using the supplied M10X25mm hardware.




Step 5: Next, tighten the three lower bolts first, following with the three upper bolts.Step 6: Repeat steps 2-5 with passenger side.Step7: Your install is now complete.



I-SHEET NUMBER: INST-00103 PART NUMBER: F194RKRCC , F194RKRCCS4 PRODUCT: RKR RAILS APPLICATION: 2019 + FORD RANGER CREW CAB

## PRT# JPTS32 Detachable Step Installation.

**Step 1:** Attach the step to the mounts located in between the RKR rails using the supplied  $1/2" \ge 1"$  flanged hex bolts and 1/2"" flanged hex nuts. **NOTE: The step will mount to the left of the bracket opposite of the weld.** 



Step 2: Torque bolts to a target of 40 ft/lbs. / 54nm