



# Installation Instructions

## Hi-Lift Mount

Product Number: M2150  
For application with the Y1261T Tire Carrier

## SAFETY

### Your safety and the safety of others is very important.

- In order to help you make informed decisions about safety, we have provided installation instructions and other information.
- These instructions alert you to potential hazards that could hurt you or others.
- Please do a job safety analysis (JSA) before each task to identify potential hazards for your situation and remove/protect against them.
- You must use your own good judgment, and take your time.

**Read and understand all safety precautions and instructions before installing this product.**

THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.

**CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.**

## Injury hazard

### Failure to observe these instructions could lead to severe injury or death.

- Always** remove jewelry and wear eye protection.
- Always** use extreme caution when jacking up a vehicle for work. Set emergency brake and use tire blocks. Locate and use the vehicle manufacturers designated lifting points. Use jack stands.
- Always** use appropriate and adequate care in lifting components into place.
- Always** insure components will remain secure during installation and operation.
- Always** wear safety glasses when installing this kit. A drilling operation will cause flying metal chips. Flying chips can cause serious eye injury.
- Always** use extreme caution when drilling on a vehicle. Thoroughly inspect the area to be drilled (on both sides of material) prior to drilling, and relocate any objects that may be damaged.
- Always** use extreme caution when cutting and trimming during fitting.
- Always** tighten all nuts and bolts securely per installation instructions.
- Always** route electrical cables carefully. Avoid moving parts, components that become hot and rough or sharp edges.
- Always** insulate and protect all exposed wiring and electrical terminals.
- Always** perform regular inspections and maintenance on mounts and related hardware.





# Installation Instructions

## Hi-Lift Mount

Product Number: M2150

For application with the Y1261T Tire Carrier

### I. Overview

Congratulations on your new purchase of the Jeep JK Hi-Lift Mount accessory. This Hi-Lift Mount was designed in conjunction with the Y1261T off the door tire carrier to provide a stylish and strong solution to mounting your Hi-Lift.

Your Hi-Lift Mount was designed in 3-D from digitized data, CNC laser cut, fabricated, and powder coated... all in the U.S.A. Enjoy the fit and finish of a quality Jeep Tire Carrier and Hi-Lift Mount from Fab Fours, Inc.

**WARNING:** This product was designed to be used with the Fab Fours JK Tire Carrier ONLY.





# Installation Instructions

## Hi-Lift Mount

Product Number: M2150

For application with the Y1261T Tire Carrier

### II. Tools Required

- 7/16" and 3/4" Wrenches and sockets
- Socket wrench and short extension

### III. Hi-Lift Accessory Installation

1. Using the provided ¼ hardware, attach the Hi-Lift Mount in the same configuration as the picture shown above.
2. Mount your Hi-Lift and use the two provided ½-20 bolts to attach it.

### *Maintenance/Care*

- Periodically check and tighten all nuts.
- Stripped, fractured, or bent bolts or nuts need to be replaced.
- Periodically grease the tire carrier pivot.
- Periodically check the tension of the latch hook..

